

# CONTINUED COVERAGE FOR YOUR NEW, USED, OR CERTIFIED PRE-OWNED BMW.

Whether your original 4-year/50,000-mile BMW Warranty is coming to an end, or you want to extend your BMW Certified Pre-Owned (CPO) Protection Plan, adding extra time and mileage is easy.

With BMW Extended Vehicle Protection, you can drive with the confidence of being covered up to 7 years/100,000 miles - with benefits you won't find anywhere else:

- Use of only 100% original BMW replacement parts.
- Covered repairs performed at an authorized BMW repair facility by trained BMW technicians.
- 24-hour BMW Roadside Assistance<sup>1</sup>.
- Protection of your vehicle's performance and resale value.

**Contact your BMW Center about BMW Extended Service Contracts today.** 

1.24-Hour Roadside Assistance Benefits are provided by Signature Motor Club, Inc. and Signature Motor Club of California, Inc., 200 N. Martingale Road, Schaumburg, IL 60173.

# BMW EXTENDED SERVICE CONTRACTS

Financial Services

bmwusa,com/fs



## CHOOSE THE LEVEL OF COVERAGE YOU NEED.1

## PLATINUM (New, used, and CPO BMW)

The highest level of protection for your BMW. Includes comprehensive coverage of most major components plus protection not offered in any other package.

#### ■ Comprehensive coverage:

- · Engine
- Transmission
- · Final Drive Assembly
- · Transfer Case (all-wheel-drive only)
- · Electrical
- · Cooling System
- · Fuel System

- · Induction System
- Steering
- · Brakes and ABS
- · Heat and A/C
- · Infotainment System

#### □ Limited coverage:

· Interior and Exterior

# SELECT THE LENGTH OF EXTENDED PROTECTION YOU WANT.<sup>2</sup>

### New and used BMW • • •

5 years / 75,000 miles

5 years / 100,000 miles

6 years / 75,000 miles

6 years / 100,000 miles

7 years / 75,000 miles

7 years / 100,000 miles

#### **CPO BMW** •

6 years / 100,000 miles

7 years / 100,000 miles

## GOLD (New and used BMW)

Provides comprehensive coverage of many major components of your BMW - including your engine, transmission, drivetrain, and more.

#### Comprehensive coverage:

- ·Engine
- Transmission
- · Final Drive Assembly
- · Transfer Case (all-wheel-drive only)
- · Cooling System
- · Fuel System
- · Induction System
- ·Steering
- · Brakes and ABS
- · Heat and A/C

### Limited coverage:

- · Electrical
- · Interior and Exterior

#### ■ No coverage:

· Infotainment System

BMW Extended Vehicle Protection offers a worryfree ownership experience only BMW delivers - so you can enjoy everything Beyond the Drive™ as much as the drive itself.

**Contact your BMW Center about BMW Extended Service Contracts today.** 

# POWERTRAIN PLUS (New and used BMW)

Offers comprehensive coverage of many major drivetrain components with limited coverage of other parts.

### Comprehensive coverage:

- · Transfer Case (all-wheel-drive only)
- · Induction System

### Limited coverage:

- Engine
- · Transmission
- · Final Drive Assembly
- · Electrical
- · Cooling System
- · Fuel System

#### ■ No coverage:

- · Steering
- · Brakes and ABS
- · Heat and A/C
- · Interior and Exterior
- · Infotainment System
- 1. Coverage may be extended up to 7 years/100,000 miles from the original vehicle in-service date (whichever comes first). For new or used BMW vehicles, the three coverage level options (Powertrain Plus, Gold, Platinum) are available if your vehicle is under the BMW New Vehicle Limited Warranty at the time of vehicle enrollment. For Certified Pre-Owned BMW vehicles, your coverage option is Platinum if your vehicle is under the BMW CPO Protection Plan at the time of vehicle enrollment. Please check with your dealer regarding eligibility requirements.
- 2. For example, if the new vehicle sales date was 6/12/2014 and you purchase a 6-year/100,000-mile term, your coverage under this program will expire on 6/11/2020 or when the reading on your odometer reaches 100,000, whichever comes first - regardless of the contract purchase date or mileage at the contract purchase date.

bmwusa.com/fs



	PLATINUM	GOLD	POWERTRAIN PLUS
ENGINE	•	•	•
Camshaft and bearings	•	•	•
Connecting rods	•	•	•
Crankshaft	•	•	•
Cylinder block	•	•	•
Cylinder head(s)	•	•	•
Cylinder head gasket(s)	•	•	
Dipstick assembly	•	•	•
Flywheel/ring gear	•	•	•
Front and rear radial oil seals	•	•	-
Hydraulic valve clearance compensators (lifters)	•	•	•
Intake and exhaust manifolds	•	•	•
Intake manifold gasket	•	•	
Main and connecting rod bearings	•	•	•
Oil pan	•	•	•
Oil pan gasket(s)	•	•	
Oil pump assembly	•	•	•
Piston rings and pins	•	•	•
Pistons	•	•	•
Rocker arms and shafts	•	•	•
Sprockets	•	•	•
Timing chains and/or belts	•	•	•
Upper and lower timing case cover gasket(s)	•	•	
Upper and lower timing case covers	•	•	•
Upper spring plates (retainers)	•	•	•
Valve collets, guides, and seals	•	•	•
Valve cover(s)	•	•	•
Valve cover gasket(s)	•	•	
Valve springs	•	•	•
Valves	•	•	•
Vibration damper	•	•	•
TRANSMISSION	•	•	•
All sprockets, shaft bearings, bushings, drums, pumps and valves	•	•	•
Drive plate for torque converter	•	•	•
Flywheel	•	•	•

bmwusa.com/fs



	PLATINUM	GOLD	POWERTRAIN PLUS
TRANSMISSION (CONTINUED)	•	•	•
Torque converter	•	•	•
Transmission case	•	•	•
Transmission oil seals and gaskets	•	•	
FINAL DRIVE ASSEMBLY	•	•	•
All sprockets, bearings and output shafts	•	•	•
CV joints	•	•	•
Final drive housing	•	•	•
Flexible gaiters (CV joint boots)	•	•	
Front and rear hub assembly	•	•	•
Hub bearings	•	•	•
Input and output flange seals and gaskets	•	•	
Propeller shafts	•	•	•
Rear housing cover gasket	•	•	
Universal joints	•	•	•
TRANSFER CASE (XDRIVE VEHICLES ONLY)	•	•	•
All sprockets, shaft bearings, bushings, drums, pumps and valves	•	•	•
ELECTRICAL	•	•	•
All gauges	•	•	
Alternator/generator	•	•	•
Comfort access/power door lock actuators	•		
Control modules	•	•	
Convertible top storage lid and top drive motors	•	•	
Cruise control switch, actuator and control module	•	•	
Electronic mirror motors and switches	•	•	
Engine and transmission control modules	•	•	•
Front and rear main wiring harnesses	•	•	
Horn contacts, brush, contact rings assembly and horns	•	•	
Instrument and service indicator circuit boards	•	•	
LCD display modules and coding plugs	•	•	
Manually and electrically operated switches	•	•	

bmwusa.com/fs



	PLATINUM	GOLD	POWERTRAIN PLUS
ELECTRICAL (CONTINUED)	•	•	•
On-board computer	•	•	
Power door and central locking systems	•	•	
Power mirror motors	•		
Power seat drive	•	•	
Power window motors	•	•	
Rear window defogger	•	•	
Rear window wiper motor	•	•	
Remote electronic entrance system	•	•	
Starter motor	•	•	•
Starter solenoid	•	•	•
Sunroof motor and gear	•	•	
Turn signal/headlight dimmer switch	•	•	
Voltage regulator	•	•	•
Windshield wiper delay switch	•	•	
Windshield wiper motor	•	•	
COOLING SYSTEM	•	•	•
Additional fan motor	•	•	•
Coolant recovery tank	•	•	•
Fan clutch	•	•	•
Fan surround	•	•	
Idler pulley/belt tensioner	•	•	
Radiator	•	•	•
Water pump	•	•	•
FUEL SYSTEM	•	•	•
Fuel injection and air flow sensors	•	•	•
Fuel injectors	•	•	•
Fuel pumps (including high-pressure pump)	•	•	•
Fuel tank	•	•	
Metal and plastic lines and fittings	•	•	•
Piezo injectors	•	•	•
INDUCTION SYSTEM	•	•	•
Turbocharger assemblies (vehicles so equipped)	•	•	•

bmwusa.com/fs



	PLATINUM	GOLD	POWERTRAIN PLUS
SCR (SELECTED CATALYST REDUCTION) EMISSION CONTROL SYSTEM (DIESEL MODELS ONLY)	•	•	•
Dosing module	•	•	•
Transfer pump	•	•	•
STEERING	•	•	
All internally lubricated parts within the steering box	•	•	
Cooler and lines	•	•	
Power steering pump	•	•	
Rack-and-pinion assembly	•	•	
Steering box housing	•	•	
Steering shaft and couplings	•	•	
BRAKES & ABS	•	•	
ABS control module	•	•	
ABS hydraulic pump assembly	•	•	
ABS relays	•	•	
ABS wheel speed sensors	•	•	
Brake booster assembly	•	•	
Brake calipers	•	•	
Brake pedal assembly	•	•	
Hydraulic lines and fittings	•	•	
Master cylinder	•	•	
Parking brake assembly	•	•	
Wheel cylinders	•	•	
HEATING/AIR CONDITIONING SYSTEM	•	•	
Auxiliary water pump	•	•	
Compressor	•	•	
Compressor clutch and pulley	•	•	
Condenser	•	•	
Evaporator	•	•	
Expansion valve	•	•	

BMW Financial Services Extended Service

bmwusa,com/fs



## **BMW EXTENDED SERVICE CONTRACTS** COVERAGE LEVEL OPTIONS AT-A-GLANCE.

	PLATINUM	GOLD	POWERTRAIN PLUS
HEATING/AIR CONDITIONING SYSTEM (CONTINUED)	•	•	
Heater and air conditioner blower	•	•	
Heater control valve	•	•	
Heating and A/C control panel and control module	•	•	
Idler pulley/belt tensioner	•	•	
Receiver-drier	•	•	
Stepper motors	•	•	
INTERIOR AND EXTERIOR	•	•	
Cup holders	•		
Front seat tracks/rails	•	•	
Head lamps, head lamp assemblies and lenses	•		
Shift lever	•	•	
Trunk and hood gas pressure struts	•	•	
INFOTAINMENT SYSTEM	•		
CD player/changer	•		
Entertainment system	•		
Navigation system and components	•		
Radio	•		

Obligor: BMW of North America, LLC, 300 Chestnut Ridge Road, Woodcliff Lake, NJ 07677-7731, 800-831-1117. In Florida and Oklahoma, the obligor is: BMW Extended Service Corporation, 300 Chestnut Ridge Road, Woodcliff Lake, NJ 07677-7731, 800-831-1117, FL License Number: 65501. Special Note: Coverage under this program is limited to defects in material or workmanship only. Wear and tear is the responsibility of the vehicle owner. This brochure is a summary of some of the benefits available with BMW Extended Vehicle Protection and should not be relied upon when purchasing coverage. Please refer to the Customer Contract for specific coverage details. Changes may have been made to the BMW Extended Vehicle Protection program since the printing of this brochure. All transactions related to the BMW Extended Vehicle Protection program are governed solely by the provisions of the Customer Contract. See your actual Customer Contract for details of coverage, as well as terms, conditions and costs.

© 2016 BMW Financial Services NA, LLC. The BMW wordmark, BMW logo and Beyond the Drive are trademarks of BMW AG.